

POWERFLEX®

PART NUMBER

PFF1-801

DESCRIPTION

FRONT LOWER WISHBONE FRONT BUSH

INSTALLATION GUIDE

Contents (parts per pack):

- 4 x Polyurethane Bushes
- 1 x PTFE/Silicone Grease
- 2 x Washer-Fitted Stainless Steel Sleeves
- 2 x Zinc Plated Mild Steel Washers

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.

Notes:

- These bushes are designed to fit genuine control arms. If non-genuine arms are fitted and you find the stainless steel sleeve does not fit onto the wishbone, please contact us by email with the dimensions required and we will send you a set of the correct sized sleeves free of charge.

- WE RECOMMEND THE USE OF LOCTITE 648 OR 848 TO SECURE CENTRE SLEEVE TO ARM

Fitting Instructions:

1. Remove the front lower wishbone from the car.
2. Remove the original rubber bushes from the front of the wishbone, and clean off any dirt or corrosion from the wishbone.
3. Push the washer-fitted sleeve onto the wishbone with the washer first.
4. Apply some of the supplied grease to the sleeve.
5. Push the polyurethane part onto the sleeve so the lip sits on the washer, and then push the second polyurethane part onto the wishbone with the lip last, as shown in figure 1.
6. When refitting the wishbone, place a washer on the end of the polyurethane bush and tension all hardware to manufacturers recommended torque settings.

