



PART NUMBER

**PFF5-6\*\*1**

DESCRIPTION

FRONT RADIUS ARM TO CHASSIS BUSH

### INSTALLATION GUIDE

#### Contents (parts per pack):

4 x Polyurethane bushes      1 x PTFE Silicone Grease  
2 x Stainless steel sleeves

*Please read the complete fitting instructions and check package components before fitting.*

*These fitting instructions are to be used as a guide and in conjunction with workshop manual.*

*It is recommended that:*

- all work to be carried out by a licensed technician;*
- all safety precautions adhered to;*
- wheel alignment to be checked and adjusted as required after any suspension work.*

*All fasteners must be tensioned to manufacturer's torque settings.*



#### Fitting Instructions:

1. Remove original bush from arm.
2. Clean any dirt and corrosion from bore in arm, removing any sharp edges around bore using a file.
3. Fit the polyurethane bushes into arm.
4. Apply supplied grease in and around bore of polyurethane bushes.
5. Insert stainless steel sleeve into bush as shown in *Figure 1*.
6. Refit arm to the car. Tension all hardware to manufacturers recommended torque settings.

