



PART NUMBER

PFF3-701

DESCRIPTION

FRONT CONTROL ARM BUSH

INSTALLATION GUIDE

Contents (parts per pack):

- 4 x Polyurethane bushes
- 4 x Steel washers
- 2 x Stainless steel sleeves
- 1 x Grease

Please read the complete fitting instructions and check package components before fitment.

These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.

All fasteners must be tensioned to manufacturer's torque settings.



Fitting Instructions:

1. Remove the original bush from the arm.
2. Clean any dirt and corrosion from the bore in the arm. Remove any sharp edges from the bore of the arm.
3. Insert each polyurethane bush into bore of the arm, with lipped face facing outwards.
4. Apply grease into bore and mounting faces of each polyurethane bush.
5. Fit the stainless steel sleeve into bush.
6. Place washers flush against top face of polyurethane bushes.
- 7 Re-fit arm to the car. Tension all hardware to manufacturers recommended torque settings.

