

POWERFLEX®

PART NUMBER
PFR5-426

DESCRIPTION
REAR DIFF REAR BUSH

INSTALLATION GUIDE

Product description:

This bush offers reduced movement on the rear diff which results in a reduction of the initial torque lost during acceleration

Contents (parts per pack):

- 1 x bush
- 1 x stainless steel sleeve
- 1 x metal washer
- 1 x grease

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual. It is recommended that:

- all work to be carried out by a licensed technician;
 - all safety precautions adhered to;
 - wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.*

Fitting Instructions:

1. Remove the original bush from the subframe.
2. Fit the polyurethane bush into the subframe pushing it in from the front towards the rear of the car so the larger diameter is facing the diff.
3. Using the supplied grease apply to the bore of the bush and the outside of the stainless steel sleeve. Push the sleeve through the bush.
4. Place the washer on the larger diameter so it sits between the diff and the bush, use the original bolt and washer and refit as necessary.

