

# POWERFLEX®

## PART NUMBER

# PFF60-701

## DESCRIPTION

# FRONT ARM REAR BUSH

## INSTALLATION GUIDE

### Contents (parts per pack):

2 x Polyurethane Bushes      1 x PTFE/Silicone Grease  
2 x Stainless Steel Sleeves    4 x Zinc Plated Mild Steel Washers

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.



### Fitting Instructions:

1. Remove the original rubber bush from the arm including the outer shell.
2. Clean any dirt and corrosion from the hole in the arm and file off any sharp edges to avoid damaging the new bush.
3. Press the Powerflex bush into the vacant hole in the arm so that the flanges of the bush protrude each side of the arm fully as shown in figure 2.

**Tip: it may be necessary to apply some washing up liquid to the outside of the bush to ease fitting.**

4. Apply some of the supplied grease to the bore of the Powerflex bush and press in the stainless steel sleeve until flush at both ends.
5. Place the supplied washers on both faces of the bush and refit the arm to the subframe of the car.
6. Please re-tighten all fasteners to the manufacturer's recommended torque settings.

