

POWERFLEX®

PART NUMBER
PFF66-208

DESCRIPTION
FRONT SUBFRAME MOUNTING BUSH

INSTALLATION GUIDE

Product description:

Replaces the original rubber subframe mounting bushes giving a more positive location of the subframe, easier to fit than original bushes.

Contents (parts per pack):

- 6 x bushes
- 6 x stainless steel sleeves
- 6 x metal washers
- 1 x grease



Please read the complete fitting instructions and check package components before fitment.

These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.

All fasteners must be tensioned to manufacturer's torque settings.

Fitting Instructions:

1. Support the subframe, loosen one side of the subframe then remove the other sides mounting bolts, allow the subframe to lower on that side to allow access to the bush.
2. Remove the original mounting bush, keeping the original bolt and washer to reuse.
3. The new Powerflex polyurethane bush fits into the subframe from the top side, place the tapered end down into the hole pull the bush into the subframe.

Tip: apply some washing up liquid the the outside of the bush and the subframe to ease fitment.

4. Using the supplied grease apply to the bore of the bush and push sleeve in.
5. The washer fits between the top face of the bush and the chassis, use the original bolt and washer when refitting.

