

POWERFLEX®

PART NUMBER

PFR80-1211

DESCRIPTION

REAR UPPER ARM (BANANA) - OUTER BUSH

INSTALLATION GUIDE

Product description:

This bush incorporates a spherical bearing allowing articulation of the arm.

Contents (parts per pack):

- 2 x bushes (2 x assembled capsules)
- 4 x metal spacers (2 x short & 2 x long)



Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.

All fasteners must be tensioned to manufacturer's torque settings.

Fitting Instructions:

1. Remove the rear upper arm, sometimes referred to as the banana arm due to its shape.
2. Press out the original bush, these can be tight.
3. Place the leading edge of the bush capsule into the arm and press the unit in so it finishes central in the arm. Ideally a press should be used but you can use a vice.
4. Refit the arm to the car, place the shorter of the spacers between the upright and bush with the smaller end nearest the bearing. The longer of the spacers goes on the outside face of the bearing again with the smaller end towards the bearing. Fit the original bolt through the complete assembly and tighten.

