

# POWERFLEX®

PART NUMBER

**5-6102**

DESCRIPTION

**FRONT CONTROL ARM TO CHASSIS BUSH**

## INSTALLATION GUIDE

### Contents (parts per pack):

2 x Polyurethane Bushes 4 x Zinc Plated Mild Steel Washers

2 x Stainless Steel Sleeves 1 x Grease

4 x Zinc Plated Mild Steel Shells

*Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.*

*It is recommended that:*

*-all work to be carried out by a licensed technician;*

*-all safety precautions adhered to;*

*-wheel alignment to be checked and adjusted as required after any suspension work.*

*-All fasteners must be tensioned to manufacturer's torque settings.*

### Fitting Instructions:

1. Remove the original arm from car.
2. Press the original bushes out of the arm.
3. Remove any dirt and check for any corrosion.
4. Apply a small amount of supplied grease to the outside of the bush and press into shells.
5. Apply supplied grease to the knurled bore of the bush and press sleeve into the bore.
6. Refit arm to car, placing washers on the outside of the bushes.
7. Tension all hardware to manufacturers recommended torque settings.

