

# POWERFLEX®

PART NUMBER

**PFF1-503-\***

DESCRIPTION

**FRONT ANTI ROLL BAR BUSH**

## INSTALLATION GUIDE

### Contents (parts per pack):

2 x bushes

1 x grease

*Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.*

*It is recommended that:*

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.

*All fasteners must be tensioned to manufacturer's torque settings.*



### Fitting Instructions:

1. Remove front anti roll bar from the car.
2. The original bracket needs to be reused. There are two rivets which need to be drilled out with a suitable size drill.
3. The opposing side to the rivets needs the swage to be removed to allow the bracket to be removed. This can be done with 18mm drill. Only remove the swage do not drill all the way through.
4. Remove the original bush, clean any rust and dirt from the bar and brackets.
5. Apply some of the supplied grease to the bore of the new bush, fit the bush over the bar, place the 2 pieces of the bracket over the bush.
6. Refit the anti roll bar back onto the car. The bolts will secure the bracket around the bush.

