



PART NUMBER

PFF5-1901

DESCRIPTION

FRONT RADIUS ARM TO CHASSIS BUSH

INSTALLATION GUIDE

Contents (parts per pack):

- 4 x Polyurethane bushes
- 2 x Steel washers
- 2 x Stainless steel sleeves
- 1 x Grease

Please read the complete fitting instructions and check package components before fitment.

These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
 - all safety precautions adhered to;
 - wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.



Fitting Instructions:

1. Remove original bush from arm.
2. Clean any dirt and corrosion from bore in arm, removing any sharp edges around bore.
3. Fit the polyurethane bush into arm.
4. Fit steel washer on stainless steel sleeve.
5. Apply supplied grease in and around bore of polyurethane bushes.
6. Insert stainless steel sleeve into bush from inside of the vehicle, with thicker lip positioned towards the centre of the vehicle, as shown in *Figure 1*.
7. Ref t arm. Tension all hardware to manufacturers recommended torque settings.

