

**PART NUMBER****PFF76-423****DESCRIPTION****REAR GEARBOX MOUNT BUSH****INSTALLATION GUIDE****Contents (parts per pack):**

2 x Polyurethane Bushes 1 x Silicone / PTFE Grease
1 x Stainless Steel Sleeves

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;*
- all safety precautions adhered to;*
- wheel alignment to be checked and adjusted as required after any suspension work.*
- All fasteners must be tensioned to manufacturer's torque settings.*

**Fitting Instructions:**

Note: PFF76-423 Replaces the rear gear box mounting bush on Toyota Starlet GT Turbo EP82 and Toyota Starlet Glanza V Ep91 models that come with a Limited Slip Differential LSD as standard from Toyota.

1. Remove mount from the car.
2. Remove the original bush including the outer shell from the bracket.
3. Clean any rust and dirt from the bracket.
4. Insert the polyurethane bushes, align the cut out on the bush to miss the casting web of the bracket on one side.
5. Apply the supplied grease to the bore of the bush and the outside of the stainless steel sleeve, push the sleeve through the bush.
6. Refit the mount to the car.

