

POWERFLEX®

PART NUMBER

19-101

DESCRIPTION

Front Outer Track Control Arm Bush

Contents (parts per pack):

4 x Polyurethane Bushes 4 x Mild Steel Washers
2 x Stainless Steel Sleeves 2 x M16 Nylock Nuts
1 x PTFE/Silicone Grease

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.

Fitting Instructions:

1. Remove the arm from the vehicle and press out the original bush including the outer shell.
2. Clean any dirt and corrosion from the bore of the arm, removing any sharp edges or burrs around the bore with a rounded file.
3. Fit the polyurethane bushes to the control arm as shown in Fig 1.
4. Apply some of the supplied grease to the bore of the bush.
5. Insert the stainless steel sleeve into the bush until sitting flush at both ends.
6. Place one washer onto the anti-roll bar taking note of the shape and how this will mate with the bush shape.
7. Fit the control arm onto the anti-roll bar, followed by the second washer and M16 nut. Finger tighten to maintain the washer position.
8. Re-fit the arm to the vehicle and tighten the M16 nut.
9. Tension all hardware to manufacturers recommended torque settings.

INSTALLATION GUIDE




Figure 1