

**PART NUMBER****PFF5-1322****DESCRIPTION****GEARBOX MOUNTING BUSH INSERT****INSTALLATION GUIDE****Contents (parts per pack):**

1 x PFF5-1322 Polyurethane Bush

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.

**Fitting Instructions:**

1. Support the engine from underneath using a trolley jack and a block.
2. Locate the gearbox mount on the right-hand side of the engine bay. This will involve removing the headlight, airbox, battery, and then the battery tray, etc.
3. Unbolt the gearbox mount and proceed to remove it from the vehicle. This will require some adjustment of the engine/gearbox height using the jack and some manouvering of the mount.
4. Clean any dirt from within the voids of the rubber mount and remove any flashing lines.
5. Insert the bush into the void at the top of the OE rubber mount.
6. Refit the mount to the car and tighten all hardware to the manufacturer's recommended torque settings.

