

**PART NUMBER****PFR3-743****DESCRIPTION****REAR DIFF REAR BUSH INSERT****INSTALLATION GUIDE****Product Description:**

This part inserts into the bush with the OEM number: 8K0 599 257 N

Contents (parts per pack):

2 x Polyurethane Insert	2 x Steel Washers
2 x Stainless Steel Sleeves	2 x M12 Washers
1 x M12 Bolt	1 x PTFE / Silicone Assembly Grease

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.

**Fitting Instructions:**

1. Clean any dirt or debris from the inside of the original diff mounting bush.
2. Apply some PTFE / silicone grease to the prongs of the polyurethane insert and press into the voiding of the original bush.
3. Insert the stainless steel sleeve into bore of polyurethane insert.
4. Fit the supplied large plated steel washer to the bush assembly, followed by the plated M12 washer and supplied M12 bolt.
5. Tighten the M12 bolt into the vehicle differential to manufacturer's recommended torque.

