

POWERFLEX®

PART NUMBER

PFR57-415

DESCRIPTION

ENGINE/TRANSMISSION CARRIER BUSH

INSTALLATION GUIDE

Contents (parts per pack):

- 2 x Polyurethane A Bushes
- 2 x Polyurethane B Bushes
- 2 x Stainless Steel Sleeves
- 1 x PTFE Silicone Grease

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.



Fitting Instructions

1. Press out the original rubber bush from the bracket and clean away any dirt and corrosion, removing any sharp edges with a rounded file. Retain the original washers.

2. Insert **Bush A** into the top of the bracket, ensuring it sits flush within the body. Please refer to **Fig. 1**.

3. Insert **Bush B** into the bottom of the bracket, ensuring it sits flush within the body of bracket and within the recessed bore of **Bush A**.

4. Apply some of the supplied **grease** to the outside of the **stainless steel sleeve** and bore of the bushes. Press the sleeve into the bushes, until flush.

5. Refit the **bracket** to the vehicle reusing the original washers.

6. Tension all hardware to the manufacturer's recommended torque settings.

