

POWERFLEX®

PART NUMBER

PFR5-420

DESCRIPTION

REAR SUBFRAME FRONT MOUNTING BUSH

INSTALLATION GUIDE

Contents (parts per pack):

2 x Polyurethane A Bushes 2 x Aluminium sleeves
2 x Polyurethane B Bushes 1 x PTFE/Silicone Grease

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;*
- all safety precautions adhered to;*
- wheel alignment to be checked and adjusted as required after any suspension work.*
- All fasteners must be tensioned to manufacturer's torque settings.*

Fitting Instructions:

1. Remove original rear subframe front bush.
2. Fit the polyurethane A bush from the top.
3. Fit the polyurethane B bush from the bottom. The b bush has a radius to the bore to allow the base plate to fit correctly.
4. Apply the supplied grease to the bore of the bushes and insert the aluminium sleeve making sure the end with the counter bore is facing up towards the chassis, locating on the pin of the chassis.
5. Refit using the original washer plate and tension all hardware to manufacturers recommended torque settings.



Counter bore



A Bush

B Bush



Top view



Bottom view

