



PART NUMBER

PFF79-104

DESCRIPTION

FRONT LOWER WISHBONE FRONT BUSH

INSTALLATION GUIDE

Contents (parts per pack):

- 2 x Polyurethane bushes
- 2 x Stainless steel sleeves
- 2 x Delrin washers
- 1 x grease



Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual. It is recommended that:

- all work to be carried out by a licensed technician;
 - all safety precautions adhered to;
 - wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.*

Fitting Instructions:

1. Remove original bush from the arm, clean any dirt and rust from bore in arm.
2. Push the bush into the arm from the outside bend of the arm where there is a greater angle between the outer shell and arm.
3. Place the washer on to the sleeve at the top hat end of the bush.
4. Refit arm to the car and tension all hardware to manufacturers recommended torque settings.

