

POWERFLEX®

PART NUMBER

PFF80-1211

DESCRIPTION

FRONT WISHBONE FRONT AND REAR BUSH

INSTALLATION GUIDE

Contents (parts per pack):

2 x Polyurethane Bushes with Zinc-Plated Stainless Steel Outer Shells

2 x Stainless Steel A Sleeves 2 x Stainless Steel B Sleeves

4 x Polyurethane Dust Covers 1 x PTFE/Silicone Grease

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.



Fitting Instructions:

1. Remove the original rubber bush from the front wishbone and clean away any dirt and corrosion.
2. Clean any dirt and corrosion from the bore of the wishbone, and file off any sharp edges.
3. Press the outer shell assembly into the arm so that it sits flush, as shown in figure 1.

Note: In Figure 2, the difference between the A and B sleeves is illustrated. The only difference in fitment is position in relation to the car, fitment into the polyurethane sleeve is identical for both parts.

4. Place the stainless steel sleeve into the bore of the polyurethane dust cover (as shown in figure 1.) Pull the dust cover over the stainless steel sleeve as shown in Figure 1.

5. Fit the Polyurethane Dust Cover and Stainless Steel A Sleeve into the outer shell assembly so that the face of the sleeve is facing the front of the vehicle. Fit the dust cover with the B sleeve to the opposite side as illustrated in Figure 1.

6. Refit arm to car and tighten all fasteners to the manufacturers torque settings.




Figure 2

