

POWERFLEX®

PART NUMBER

PFF57-804

DESCRIPTION

FRONT TRACK CONTROL ARM OUTER BUSH

INSTALLATION GUIDE

Contents (parts per pack):

2 x Polyurethane Bushes 1 x PTFE/Silicone Grease

2 x Stainless Steel Sleeves

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.



Fitting Instructions:

1. Remove the original rubber bush from the arm, clean any dirt and corrosion from the bore in the arm. Using a file remove any sharp edges from around the bore of the arm creating a small chamfer.

2. Liberally apply washing up liquid to the bore of the arm and the outer surface of the bush, to ease the fitment of the bush.

3. Press fit the Polyurethane Bush into the vacant hole of the arm, until the bottom lip of the Polyurethane Bush pops out of the other side of the arm.

Note: A good tip is to insert the bush into the arm at an angle so one part of the lip is already in the bore of the arm. When the bush is then pushed in, the rest of the lip will follow.

4. Apply the PTFE silicone grease liberally to the bore of the bush and the outer surface of the sleeve, and press the sleeve into the bore until it sits flush.

5. Refit and tension all hardware to manufacturers recommended torque settings.



1. Applying Washing Up Liquid



2. Angling the Bush



3. Pressing the Bush



4. Applying the PTFE Grease



5. Pressing the Stainless Steel Sleeve



6. Fitted Bush